APPENDIX D-17

Detailed test procedures for Sub-Test II-17 Internal Overload Control (IOC)

D-17.1 IOC (Criteria II-17.2.a-f) JIEO Technical Report 8249 Paragraph 5.3.8, 5.3.9 The test network configuration report form will depict the test configuration for each iteration of this Sub-Test. One Ameritich call loader or similar instrument is required on each test node. Set call loader to place calls between the Origination Node (ON) and the Destination Node (DN) on trunk group under test in both directions. Provision the call loader so that there are 3 trunks left for additional calls. Provision the test node (ON) to activate IOC. (This may have to be done by a special patch if real overload can not be

generated.) Deactivate all alternate routes.

Set up Call Loader for trunk calls at 2500 calls	Call loader completing 100% of calls	Y/N	Comments:
per hour in both directions			
Place a Routine call from ONA to DNA, ONB to	Calls complete	Y/N	7
DNB and ONC to DNC and leave off hook.			
Manually enable IOC on the Test Node (ON)	System alarm indicates overload condition.	Call	7
	loader starts to fail calls into the Test Node (ON)		
		Y/N	
	Previous three Routine calls are still active	Y/N	
Go on hook with ONA but stay off hook with	DNA call is disconnected and trunk is releas	ed Y/N	7
DNA until call releases			
Place a Routine call from DNA to ONA	DNA call does not complete and is routed to an		7
	announcement	Y/N	
Place a Routine call from ONA to DNA	Call completes	Y/N]
	ONA/DNA and ONB/DNB still active	Y/N	
Place a Priority call from DNA to ONA	DNA call does not complete and is routed to an		
	announcement	Y/N	
Place a Priority call from ONA to DNA	Call completes	Y/N	
	ONA/DNA and ONB/DNB still active	Y/N	
Deactivate IOC on the Test Node (ON)	Verify the Test Node returns to normal call		
	processing within 120 sec.	Y/N	
	Test Node provides notification of return to		
	normal status.	Y/N	
	Call loader processing calls at 100%	Y/N	
Hang up all calls	Calls disconnected	Y/N	
Place a Routine call from DNA to ONA,	Calls complete	Y/N	
DNB to ONB and DNC to ONC			
Deactivate call loader and place all calls on			
hook			